



## F00RJ00841 Injector Nozzle Nut Technical Data

SKU1: G1M1F00RJ00841

SKU2: G1Y2F00RJ00841

G2

G3

G4

CR



# DIESEL

Series Injector Nozzle Nut

0445110 0445120 0414 Piezo

## F00RJ00841 Injector Nozzle Nut Technical Data

### Content

1. F00RJ00841 Injector Nozzle Nut Introduction.....	2
1.1. F00RJ00841 Injector Nozzle Nut Basic Information.....	2
1.2. F00RJ00841 Injector Nozzle Nut Common Part Number.....	2
1.3. F00RJ00841 Injector Nozzle Nut Parameter .....	3
1.4. F00RJ00841 Injector Nozzle Nut Specifications and Dimensions Parameter .....	3
1.5. F00RJ00841 Injector Nozzle Nut Quality Control.....	3
1.6. F00RJ00841 Injector Nozzle Nut Customized Service.....	4
1.7. F00RJ00841 Injector Nozzle Nut Packing List & Size.....	4
1.8. F00RJ00841 Injector Nozzle Nut Testing Standard and Certificate.....	6
1.9. F00RJ00841 Injector Nozzle Nut Warranty Instructions .....	6
1.10. F00RJ00841 Injector Nozzle Nut Storage Standard .....	7
1.11. F00RJ00841 Injector Nozzle Nut Manufacturer.....	8
2. F00RJ00841 Injector Nozzle Nut Technical Support .....	8
2.1.F00RJ00841 Injector Nozzle Nut Utilized Location .....	8
2.2. F00RJ00841 Injector Nozzle Nut Installation .....	9
2.3. Reasons of F00RJ00841 Injector Nozzle Nut Not Working Normally.....	10
2.4. Causes of F00RJ00841 Injector Nozzle Nut Being Damaged .....	10
2.5. F00RJ00841 Injector Nozzle Nut Technical Support Obtaining Methods .....	11
2.6. F00RJ00841 Injector Nozzle Nut Measurement Tool.....	12
2.7. F00RJ00841 Injector Nozzle Nut Measurement Steps.....	12
3. F00RJ00841 Injector Nozzle Nut Purchase and Delivery .....	13
3.1. F00RJ00841 Injector Nozzle Nut Purchase Payment Term .....	13
3.2. F00RJ00841 Injector Nozzle Nut Main Sales Markets.....	14
3.3. F00RJ00841 Injector Nozzle Nut Declaration Requirements .....	14
3.4. F00RJ00841 Injector Nozzle Nut Shipping Ways.....	14
3.5. F00RJ00841 Injector Nozzle Nut Lead time .....	14
3.6. F00RJ00841 Injector Nozzle Nut Logistics Time for Destination Out of China’ s Areas.....	14
3.7. F00RJ00841 Injector Nozzle Nut Injection Packing.....	15
4.F00RJ01101 Injector Nozzle Nut Storage Standard .....	15
5.Company Information.....	16
5.1. Company Introduction.....	16
5.2. Contact Information .....	17
6.Copyright Statement.....	17

**F00RJ00841 Injector Nozzle Nut Technical Data****1. F00RJ00841 Injector Nozzle Nut Introduction****1.1. F00RJ00841 Injector Nozzle Nut Basic Information**

Injector Nozzle Nut Title	Common Rail F00RJ00841 Injector Nozzle Nut China Made New
SKU 1	G1M1F00RJ00841
SKU 2	G1Y2F00RJ00841

**1.2. F00RJ00841 Injector Nozzle Nut Common Part Number****(1) Injector Nozzle Nut Applicable Injector Model**

Injector Part Number	Injector Part Number	Injector Part Number	Injector Part Number
0445120007	0445120050	0445120054	0445120057
0445120059	0445120123	0445120369	/

**(2) Injector Nozzle Nut Application Information**

Brand	Car Model	Engine Model	OE Part Number
For AGRAL	MA 12.0 E-tronic	ISBe4	2R0198133
For DODGE	Ram 3500 6.7 Pickup	/	3 999 834
For CASE	580 SN	445TA	2855 491
For CASE IH (CASE INTERNATIONAL)	Maxxum 115 Multicontroller	NEF	2854608
For KOMATSU	BR380JG-1E0	SAA6D107	6754-11-3011
For CUMMINS	/	ISBe-4cyl	4 937 065
For TATA (TELCO)	Prima 4928 S	ISB	278607990157

**(3) Injector Nozzle Nut Part Number Common Writing**

0445120007, 0445120018, 0445120028, 0445120032, 0445120046, 0445120050, 0445120054, 0445120057, 0445120059, 0445120060, 0445120069, 0445120071, 0445120075, 0445120078, 0445120079, 0445120103, 0445120113, 0445120114, 0445120123, 0445120124, 0445120132, 0445120151, 0445120152, 0445120161, 0445120177, 0445120182, 0445120183, 0445120184, 0445120185, 0445120187, 0445120188, 0445120193, 0445120204, 0445120208, 0445120209, 0445120210, 0445120211, 0445120212, 0445120231, 0445120238, 0445120239, 0445120242, 0445120247, 0445120250, 0445120251, 0445120252, 0445120254, 0445120255, 0445120256, 0445120262, 0445120263, 0445120267, 0445120269, 0445120273, 0445120289, 0445120323, 0445120329, 0445120332, 0445120336, 0445120342, 0445120346, 0445120351, 0445120356, 0445120366, 0445120367, 0445120369, 0445120378, 0445120383, 0445120384, 0445120387, 0445120393, 0445120395, 0445120396, 0445120404, 0445120409, 0445120414, FOORJ02823, FOORJ03589, FOORJ03590, 0 445 120 007, 0 445 120 018, 0 445 120 028, 0 445 120 032, 0 445 120 046,

0 445 120 050, 0 445 120 054, 0 445 120 057, 0 445 120 059, 0 445 120 060, 0 445 120 069, 0 445 120 071, 0 445 120 075, 0 445 120 078, 0 445 120 079, 0 445 120 103, 0 445 120 113, 0 445 120 114, 0 445 120 123, 0 445 120 124, 0 445 120 132, 0 445 120 151, 0 445 120 152, 0 445 120 161, 0 445 120 177, 0 445 120 182, 0 445 120 183, 0 445 120 184, 0 445 120 185, 0 445 120 187, 0 445 120 188, 0 445 120 193, 0 445 120 204, 0 445 120 208, 0 445 120 209, 0 445 120 210, 0 445 120 211, 0 445 120 212, 0 445 120 231, 0 445 120 238, 0 445 120 239, 0 445 120 242, 0 445 120 247, 0 445 120 250, 0 445 120 251, 0 445 120 252, 0 445 120 254, 0 445 120 255, 0 445 120 256, 0 445 120 262, 0 445 120 263, 0 445 120 267, 0 445 120 269, 0 445 120 273, 0 445 120 289, 0 445 120 323, 0 445 120 329, 0 445 120 332, 0 445 120 336, 0 445 120 342, 0 445 120 346, 0 445 120 351, 0 445 120 356, 0 445 120 366, 0 445 120 367, 0 445 120 369, 0 445 120 378, 0 445 120 383, 0 445 120 384, 0 445 120 387, 0 445 120 393, 0 445 120 395, 0 445 120 396, 0 445 120 404, 0 445 120 409, 0 445 120 414, F OOR J02 823, F OOR J03 589, F OOR J03 590, F00RJ00841, F OOR J00 841, 2R0198133, 2830 957, 2830224, 4 897 271, 2 830 957, 2 830 244, 1405332, 1407306, 1409652, BG5X 9E526 AA, 4896444, 2830221, 3230159500, 4897271, 2830957, 2R0 130 201 A, 394 7550, 3 949 619, 504055805, 3 964 273, 3 968 158, 3 972 887, 3 968 546, 3 968 846, 3 999 834, 3 999 832, 3 970 985, 2855 491, 504091504, 2855491, 2854 608, 504091505, 2854608, 397 6372, 3 976 372, 4 945 969, 6754-11-3011, 3 977 080, 4 983 267, 3977081, 1703934, 397 6646, 3 976 646, 4 930 440, 4 940 096, 3 970 987, 2855 135, 504128307, 1112010 630, 504 117 273, 504093216, 504117273, 4 937 700, 4 940 589, 4 940 051, 5135790AD, 05135790AD, 4 937 065, D4937065, 570107999907, 1112010-631-0000, 4 945 381, 4 981 128, 4 981 126, 4 988 835, BH1X 9K526 CA, 570107999909, 5 254 261, 4 981 077, 4 981 076, 4 983 514, 5 256 034, 68210 512AA, 4 994 928, 68086 182AA, 68086182AA, 5 253 220, 5253220-NX, 68002 012AA, 68069 384AA, 68002 012AB, R8069384AA, 68027 067AA, 68027 067AB, 6806 9384AA, 6800 2012AA, 6800 2012AB, 5 253 221, 9864 35519, 68002 012AC, 09864 35519, 5 254 688, 5 254 682, 5 254 686, 5 254 684, 5 255 184, BG9X 9K526 BA, 2R0 198 133, 5 263 262, 5 263 316, 5135 790AD, 5135 790AB, 05135 790AC, R5135790AF, 05135 790AD, 5135 790AC, 05135 790AB, 5 263 312, 1112BF11-010, 1112BF11 010, 1112010-640-0000, 5 263 321, 5 263 314, 5 263 315, 5 263 317, 5 263 318, 5086 894AA, R8004082AC, 05086 894AA, 5 263 319, 1112010-68F-0000, 2S1112010-L20-0000, 5 269 194, 89550E0072, 8052934, 5 263 307, C5268408, C5267035, 5 262 128, 5 289 380, 4 994 925, 68210105-AA, 68210105AA, 5801496001, 5801618038, 5 303 101, 5 271 684, 278607990157, 5 310 954, 5801932928

### 1.3. F00RJ00841 Injector Nozzle Nut Parameter

Applicable System: Common Rail System

Injector Nozzle Nut Series: 120 Series

Injector Nozzle Nut Type: Electromagnetic Type

Injector Nozzle Nut Dimensions: 21×36.2×M19\*0.75

### 1.4. F00RJ00841 Injector Nozzle Nut Specifications and Dimensions Parameter

Injector Nozzle Nut Size: 6\*5\*5cm =150cm<sup>3</sup> (L\*W\*H=V)

Single Injector Nozzle Nut Weight: 25g

Injector Nozzle Nut Weight Per Box: 300g

Injector Nozzle Nut Quality: China Made New

Injector Nozzle Nut Package Size: 16cm\* 10cm \*6cm =960cm<sup>3</sup> (L\*W\*H=V)

Injector Nozzle Nut Type: High Pressure Common Rail Injector Nozzle Nut

Injector Nozzle Nut MOQ: 1pcs

### 1.5. F00RJ00841 Injector Nozzle Nut Quality Control



## (1) Injector Nozzle Nut Testing

All parts of the injector nozzle nut have undergone electrical characteristics testing, precision testing, high temperature testing, low temperature testing, withstand pressure testing, leakage testing, durability testing, and various working conditions testing.

## (2) Injector Nozzle Nut Installation

In addition, the injector nozzle nut production and installation process is quality controlled. Our company strictly follows the standard product installation data and product installation steps for installation, such as injector nozzle nut stroke test, injector nozzle nut solenoid valve tightening torque, injector nozzle nut nozzle tightening torque.

## (3) Injector Nozzle Nut Inspection

The factory inspection of the injector nozzle nut has undergone three inspections: full inspection, random inspection, and batch inspection. Different brands of test benches are used to test the same injector nozzle nut for more than three times for factory inspection, and the fuel injector nozzle nut installation testing environment are progressed in dust-free workshop.

### 1.6. F00RJ00841 Injector Nozzle Nut Customized Service

**(1) Injector Nozzle Nut Customized Service Coverage:** Meet OEM manufacturers' customization needs for shell engraving, logo engraving, injector nozzle nut internal packaging, injector nozzle nut external packaging and labels, etc.

No.	1	2
Image		
Name	Injector Nozzle Nut Packing	Color Customization: Gray, Black, White

## (2) Injector Nozzle Nut Customized Service Requirements:

The purchase of customized **injector nozzle nut** is no less than **10 pieces**.




The purchase of customized **injector nozzle nut boxes** is no less than **1000 pieces**.



⚠ When the Customized products involve the need of specify logo, the OEM manufacturer is asked to provide trademark authorization and the sample of logo image file.

⚠ Once the customized injector nozzle nut is sold, it can't be returned or exchanged if there is no quality problems.

### 1.7. F00RJ00841 Injector Nozzle Nut Packing List & Size

#### (1) Injector Nozzle Nut Spare Parts List

No.	1	2	3
Image			

Name	Injector Nozzle Nut	Injector Nozzle Nut Height	Injector Nozzle Nut Outer Diameter
Description	/	Height: 36.2mm	Outer diameter: 21mm
No.	4	5	/
Image			/
Name	Injector Nozzle Nut Inside Diameter	Injector Nozzle Nut Lining	/
Description	Inside diameter M19*0.75	Prevent bumping damage to the nozzle nut	/

⚠ Minors are prohibited from using the injector nozzle nut assembly, O-ring, nozzle protective cover, injector nozzle nut shell protective cover, oil return protective cover, VCI anti-rust bag, and bubble bag to avoid personal injury.

⚠ O-rings and nozzle washer shim are disposable installation accessories and need to be replaced when installed again.

⚠ The nozzle protective cover, injector nozzle nut shell protective cover, and oil return protective cover are recyclable accessories and can be reused.

⚠ VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.

⚠ The injector nozzle nut and the installation part duct must be treated with appropriate sealing oil during installation.

## (2) Injector Nozzle Nut Packing Size



Pic No.1

No.	Name	Injector Nozzle Nut Packing Size (cm)
1	Injector Nozzle Nut Box	16*10*6

### 1.8. F00RJ00841 Injector Nozzle Nut Testing Standard and Certificate

Shumatt can provide the factory quality inspection test report of each injector nozzle nut to ensure that each injector nozzle nut delivered meets the engine performance indicators.

BOTEN		测试报告		4.05.2019 10:42:09	
承办单位: _____ 电话: _____ 地址: _____ 传真: _____ 检测人: _____ 客户地址: _____ 电话: _____ 送检单位: _____ 传真: _____ 客户姓名: _____ 检测地址: _____ 检测名称: 检测器 规格-零件号: _____ 检测时间: _____					
<b>检测结果</b>					
检测器型号: C05002-0511 检测器品牌: 检测器品牌 检测器规格: 检测器规格 检测器数量: 检测器数量					
LOGAR TEST:	38	38	38	38	38
Ratio:	38	38	38	38	38
WAFER:	38	38	38	38	38
Mass:	231.5	231.5	231.5	231.5	231.5
TL:	28.4	28.4	28.4	28.4	28.4
EL:	14.1	14.1	14.1	14.1	14.1
VE:	4.7	4.7	4.7	4.7	4.7
检测器品牌: 检测器品牌 检测器规格: 检测器规格 检测器数量: 检测器数量 检测器品牌: 检测器品牌 检测器规格: 检测器规格 检测器数量: 检测器数量					

Pic No.2

### 1.9. F00RJ00841 Injector Nozzle Nut Warranty Instructions

#### (1) Product Warranty Conditions And Instructions

It is necessary to provide evidences include pictures, videos, or test reports which tested by the injector nozzle nut inspection equipment, and so on, to feed back to the salesman when the injector nozzle nut is abnormal during using.

The abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. Oil leakage etc.

#### (2) Injector Nozzle Nut Warranty Coverage

① After customer receives the **F00RJ00841** injector nozzle nut within 15 days , if there is a performance failure and the product has no damage on surface, customer can choose to replace it or repair it;

② If the **F00RJ00841** injector nozzle nut has performance problems during the warranty period (3 months), and it is confirmed to be product's problems after being tested, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

③ If the injector nozzle nut shell has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

**▲ Tips:** For products not covered by warranty, Shumatt can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

### (3) Injector Nozzle Nut Is Not Covered By Warranty

- ① The warranty period has expired.
- ② Injector nozzle nut failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- ③ Customer disassembles or repairs the injector nozzle nut personally resulting in damage to the injector nozzle nut.
- ④ Injector nozzle nut damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- ⑤ Injector nozzle nut failure or injector nozzle nut damage caused by non-injector nozzle nut design, technology, manufacturing, quality and other issues.
- ⑥ Injector nozzle nut failure due to system pressure exceeding system approved pressure.
- ⑦ Injector nozzle nut failure caused by system voltage exceeding approved voltage.
- ⑧ Injector nozzle nut failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- ⑨ Injector nozzle nut failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).
- ⑩ Injector nozzle nut failure caused by not following the installation angle specified in the vehicle engine maintenance manual.
- 11 Injector nozzle nut failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.
- 12 Injector nozzle nut failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.
- 13 Injector nozzle nut failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.
- 14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the injector nozzle nut connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

## 1.10. F00RJ00841 Injector Nozzle Nut Storage Standard

### (1) Choose a Suitable Storage Place

The warehouse and cargo yard where the injector nozzle nuts are stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

### (2) Strict Requirements of Warehousing

Strict inspections should be carried out when the injector nozzle nuts are put into storage, the surface



cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged injector nozzle nuts must be protected from damage.

### (3) Keep The Warehouse Dry And Preventing Moisture

The relative humidity is usually below 70% for the injector nozzle nuts placed in the room, and the corrosion of the injector nozzle nuts is significantly reduced.

Injector nozzle nuts must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

### (4) Stack Properly

After the injector nozzle nut is exposed in rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector nozzle nut from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse

If the injector nozzle nut package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

- ⚠ It is forbidden to leave the injector nozzle nut exposed in the air for a long time.
- ⚠ It is forbidden to store acid, alkali, salt and other substances together with the injector nozzle nut.
- ⚠ The unpacked injector nozzle nut must be rust-proof during secondary storage.

## 1.11. F00RJ00841 Injector Nozzle Nut Manufacturer

Injector Nozzle Nut Manufacturer: Shenzhen Shumatt Technology Co., Ltd

## 2. F00RJ00841 Injector Nozzle Nut Technical Support

### 2.1.F00RJ00841 Injector Nozzle Nut Utilized Location

E.g.: See the injector nozzle nut utilized location as follow

No.	Name
A	Injector Nozzle Nut



Pic No.3

## 2.2. F00RJ00841 Injector Nozzle Nut Installation

### (1) F00RJ00841 Injector Nozzle Nut Installation Precautions

① The replacement of the injector nozzle nut must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.

② Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the injector nozzle nut, the fitting clearance of the injector nozzle nut connection, the installation angle and tightening torque of the injector nozzle nut, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the injector nozzle nut.

③ When installing the injector nozzle nut on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the injector nozzle nut, and ensure that there is no dust, carbon deposits, water, rust spots, etc.

④ Before installing, check whether the injector nozzle nut washer shim has been replaced and installed on the injector nozzle nut.

⑤ When installing the injector nozzle nut, apply lubricant between the injector nozzle nut, fuel nozzle sealing washer shim and O-ring.

⑥ Without replacing new washer shim can lead to: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the injector nozzle nut and nozzle to break and cause damage to the engine.

⑦ When installing the injector nozzle nut on the engine, please carefully check the components

related to the installation of the injector nozzle nut, such as the injector nozzle nut pressure plate, screw, injector nozzle nut rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.

⑧ It is forbidden to operate the bare injector nozzle nut for a long time in an environment with serious dust pollution and corrosion to iron products.

⑨ It is forbidden to operate the bare injector nozzle nut for a long time in a strong magnetic field environment.

## (2) Injector Nozzle Nut Tightening Torque

When installing the injector nozzle nut, the torque wrench and tightening torque data requirement must follow the injector maintenance manual. (50Nm) .



Pic No.4

⚠ The nozzle nut tightening torque must be installed according to the tightening torque specified in the injector maintenance manual.

## 2.3. Reasons of F00RJ00841 Injector Nozzle Nut Not Working Normally

- (1) There is air in the oil circuit of the engine fuel system.
- (2) Vehicle injector nozzle nut oil supply system is not normal.
- (3) Engine common rail system oil leakage or pressure limiting valve damage.
- (4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the injector nozzle nut of the vehicle.
- (5) The long-term placement of the injector nozzle nut causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

⚠ Before installing, carefully check whether other components in the common rail system are damaged so as to prevent the injector nozzle nut from not working properly after being replaced.

## 2.4. Causes of F00RJ00841 Injector Nozzle Nut Being Damaged

- (1) Fail to operate properly according to engine maintenance manual during disassembly or installation resulting in damage to the injector nozzle nut .
- (2) The fuel oil used for the vehicle does not meet the standard cause damage to the injector nozzle nut, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.
- (3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the

lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. all above reasons can cause damage to the injector nozzle nut.

- (4) The abrasion of the oil pump produces iron powder and aluminum powder enter the injector nozzle nut and cause damage to the injector nozzle nut.
- (5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the injector nozzle nut and causing damage to it.
- (6) The injector nozzle nut is damaged due to replacement or adjustment of the relevant parts of the injector nozzle nut. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the injector nozzle nut fails to meet the original standard.
- (7) The engine is overheated and overloaded for a long time working results in damage to the injector nozzle nut.
- (8) The injector nozzle nut will be damaged naturally at the end of its working life.
- (9) The injector nozzle nut is magnetized (injector nozzle nut parts' magnetic exceeded) causing the injector nozzle nut to not work properly.

**⚠ Before replacing the injector nozzle nut, please check the engine parts carefully according to the engine maintenance manual to avoid the injector nozzle nut being damaged again after replacement.**

## 2.5. F00RJ00841 Injector Nozzle Nut Technical Support Obtaining Methods

- 1) Injector Nozzle Nut Technical Data: <https://www.injectornut.com/download/>
- 2) Injector Nozzle Nut Videos: <https://www.injectornut.com/videos/>
- 3) Injector Nozzle Nut Encyclopedia: <https://www.injectornut.com/category/news/encyclopedia/>
- 4) Injector Nozzle Nut Information Query Software:


TruckBook Parts EPC APP, Android/Apple App Store download and install, visit <http://shumatt.com> to get the download and installation tutorial.

- 5) YouTube:

Visit [https://www.youtube.com/channel/UCByvYBx7VjV\\_mAfxh\\_Hu-aw](https://www.youtube.com/channel/UCByvYBx7VjV_mAfxh_Hu-aw) to get the technical videos, stay tuned for more information.



## 2.6. F00RJ00841 Injector Nozzle Nut Measurement Tool







Pic No.5

1. Inner diameter measuring claw	7. inch/mm metric and inch conversion button
2. Limit screw	8. OFF/ON power button
3. Battery installation place	9. ZERO button
4. Ruler body	10. Push roller
5. depth measurement	11. Button battery
6. depth measurement	/

## 2.7. F00RJ00841 Injector Nozzle Nut Measurement Steps

Picture 1 Caliper: CRT085	Picture 2 Caliper: CRT085
Step 1: Choose caliper: CRT085 (Shown in Picture 1)	Step 2: First open the caliper (OFF/ON), then return the display (ZERO) to zero (as shown in Picture 2) ▲The caliper must be adjusted to zero before measuring.

	
<p align="center"><b>Picture 2</b></p> <p>Step 3: Measure the height of the F00RJ00841 nozzle nut and place it at the position shown in the picture (Shown in Picture 3)</p> <p>▲The value must be return to 0 before measuring, then the measured value is correct based on the nozzle nut is tightened by the caliper. Do not place it tilted.</p>	<p align="center"><b>Picture 3</b></p> <p>Step 4: Measure the outer diameter of the F00RJ00841 nozzle nut and place it at the position shown in the Picture (Shown in Picture 5)</p> <p>▲The value must be return to 0 before measuring, then the measured value is correct based on the nozzle nut is tightened by the caliper. Do not place it tilted.</p>
	
<p align="center"><b>Picture 4</b></p> <p>Step 5: Measure the inner diameter of the F00RJ00841 nozzle nut and place it at the position shown in the Picture (Shown in Picture 5)</p> <p>▲The value must be return to 0 before measuring, then the measured value is correct based on the nozzle nut is tightened by the caliper. Do not place it tilted.</p>	<p align="center"><b>Picture 5</b></p> <p>Step 6: Measure the hexagonal edge-to-edge diameter of the F00RJ00841 nozzle nut and place it at the position shown in the Picture (Shown in Picture 6)</p> <p>▲The value must be return to 0 before measuring, then the measured value is correct based on the nozzle nut is tightened by the caliper. Do not place it tilted.</p>

### 3. F00RJ00841 Injector Nozzle Nut Purchase and Delivery

#### 3.1. F00RJ00841 Injector Nozzle Nut Purchase Payment Term

**Payment Terms:** T/T, PayPal, Alipay, WeChat

⚠ Please contact our salesmen for specific payment information.

### 3.2. F00RJ00841 Injector Nozzle Nut Main Sales Markets

Injector nozzle nut main sales markets: Asia, Europe, North America, South America, Africa etc.

### 3.3. F00RJ00841 Injector Nozzle Nut Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

### 3.4. F00RJ00841 Injector Nozzle Nut Shipping Ways

**Destination in China areas:** SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

**Destinations out of China's areas:** DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

### 3.5. F00RJ00841 Injector Nozzle Nut Lead time

**Lead time:** Send out within 3 – 7 working days after receiving payment (Except for special products and special cases) .

### 3.6. F00RJ00841 Injector Nozzle Nut Logistics Time for Destination Out of China's Areas

**DHL Logistics Time :**

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

**UPS Logistics Time: Country or Region of Departure: China's Mainland**

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	UK	5-7Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days				

▲ The logistics time is for reference only and is subject to the actual arrival.

### 3.7. F00RJ00841 Injector Nozzle Nut Injection Packing

**Domestic express packaging:** Usually wrapped in waterproof scotch tape, such as picture No.1.




**International express packaging:** Wrapped with waterproof yellow tape after wrapping the black protective film, such as picture No. 2.

**Pallet Shipping:** Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 3, also, the products can be packaged according to customers' requirements.

▲ The packing tray is made of plastic and can be recycled.

▲ Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

▲ Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.

No.	1	2	3
Image			
Name	Domestic Express Packaging	International Express Packaging	Pallet Shipping
Description	Wrapped by transparent tape	Wrapped with yellow tape after wrapping black protective film	Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

### 4.F00RJ01101 Injector Nozzle Nut Storage Standard

#### (1)Choose a Suitable Storage Place

The warehouse and cargo yard where the injector nozzle nuts are stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

#### (2)Strict Requirements of Warehousing

Strict inspections should be carried out when the injector nozzle nuts are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged injector nozzle nuts must be protected from damage.



### (3)Keep The Warehouse Dry And Preventing Moisture

The relative humidity is usually below 70% for the injector nozzle nuts placed in the room, and the corrosion of the injector nozzle nuts is significantly reduced.

Injector nozzle nuts must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

### (4)Stack Properly

After the injector nozzle nut is exposed in rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector nozzle nut from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse

If the injector nozzle nut package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

- ⚠ It is forbidden to leave the injector nozzle nut exposed in the air for a long time.
- ⚠ It is forbidden to store acid, alkali, salt and other substances together with the injector nozzle nut.
- ⚠ The unpacked injector nozzle nut must be rust-proof during secondary storage.

## 5.Company Information



Pic No.6


### 5.1. Company Introduction


**Chinese Name:** 深圳市舒马特科技有限公司

**English Name:** Shenzhen Shumatt Technology Co., Ltd


📞 **Mob Phone/WeChat:** +86-13410541523


 **HK Telephone:** +852-67653519


 **Telephone:** +86-755-23215133


 **Email:** ruby@shumatt.com

 **Website:** www.shumatt.com

 **Shenzhen Office:** 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China Mainland

 **Shenzhen Office:** Exit C, Qiao Touxu Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

 **Hong Kong Office:** Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

 **After-sales Service Address:** Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: [1.9. F00RJ00841 Injector Nozzle Nut Warranty Instructions](#))

## 5.2. Contact Information

Name	WeChat/ WhatsApp	Email
Ruby	+86-13410541523	hison@shumatt.com

## 6. Copyright Statement

The content, design, logos, and materials contained within the file "**F00RJ00841 Injector Nozzle Nut Technical Data**" are the sole property of Shenzhen Shumatt Technology Co. and other respective copyright owners. They are safeguarded by relevant copyright and intellectual property regulations. Any reproduction, distribution, or unauthorized utilization of the content in this file without explicit written consent from Shenzhen Shumatt Technology Co., Ltd is strictly prohibited and could lead to trademark infringement. For any inquiries regarding the use or licensing of content on this website, please reach out to us at [hison@shumatt.com](mailto:hison@shumatt.com).